

14 DAYS

ENJOY!


[illegible]

STAGE 1: Takes 20-30 mins:




1. Clean and sterilise all beer making equipment. Follow the instructions on the steriliser packet.

- 25L fermenting bucket (with lid)
- Measuring jug
- Long stirring spoon
- Hydrometer
- Tin opener
- Scissors




2. Stand can of malt extract in hot water for 5 minutes to soften contents, then open the can and pour contents into the sterilised fermenter.




3. Add 2.5 litres (4.4 UK pints) boiling water to the fermenter and then mix thoroughly to dissolve the extract. **TIP:** Use 1 litre to wash out the contents of the can. Hold the can using oven gloves or a thick tea towel to avoid burning your hand.

4. Add 1kg of Muntons Light Spraymalt and stir to thoroughly mix. **TIP:** Using Muntons Spraymalt supports the health of the yeast, giving the beer more body and flavour, whilst also improving head retention. Brewing sugar can also be used but does not offer the same benefits.



5. Top up the fermenter volume to 20 litres (35 UK pints) using cold water and thoroughly mix to ensure all contents are fully dissolved. Use your hydrometer to take a gravity reading and note this down.

6. Open the yeast sachet and sprinkle across the surface of the fermenter. Securely cover the fermenter with the lid and insert an airlock. Leave to stand for 5 days in a warm place (between 15°-20°C (59°-68°F)).



STAGE 2: 1 min:

7. On day 5 of fermentation, open the hop sachet and add to the fermenter. Adding these in a hop bag may be useful as this will help to avoid hop material blocking the bottling siphon later on.



8. Return the lid and leave the fermenter for a further 5 days. Bubbles may start rising through the airlock. These must stop before moving to step 10, indicating that fermentation is complete.

9. Fermentation will be complete when bubbles cease to rise through the airlock. Check the gravity using a hydrometer. Gravity should remain constant for 48 hours. This should be at or below 1014°.

SEE STAGE 3 OVERLEAF >